

# Hitachi HT-4139


## Read This Prior to Unpacking

Read these Precautions and the Instruction manual to use the HT-4139 scanner safely and effectively. After reading, keep them on hand so you can refer to it when needed.

### 1. Common Safety Precautions

- Read the following safety precautions.
- Be sure to follow the instructions and directions in this manual when using the device.
- Personal danger or damage to device may occur when any of the precautions are ignored.
- Be sure to follow the safety notices shown on the device or mentioned in the manual.

### SAFETY MARKS




- Never attempt to do any operation not mentioned in the manual.

If you experience problems, contact your service provider.

Even though the safety notices shown on the device or mentioned in the manual are carefully considered, unexpected events may occur.

### 2. Unpacking

This device weighs approximately 110 lbs (50 kg) it is recommended that 2 people lift or move the device. The scanner should only be lifted or moved by gripping the bottom of the device. If you hold any other parts, the device may break or drop. When placing the device on the floor or table, be careful not to catch your fingers between the bottom of the device and the floor.



**CAUTION:** 2 people are required for lifting and moving the device.

### 3. Scanner Cover Removal

The devices cover should not be removed by anyone other than trained and certified service personnel. There are high-voltage components and rotating parts inside the device, which may cause electric shock, injury, or damage the device.

### 4. Safety Notice Label on Scanner

Clean each safety notice label regularly so the text can be read correctly. If the label is unreadable or damaged, please contact the service personnel and ask for a new label.

### 5. Device Installation

Refer to the Device Installation Manual for detail.

- (1) Remove the mirror protection sheet
- (2) Attach 3 trays and the stacker guide
- (3) Set the ribbon cassette
- (4) Connect the power cable on both ends
- (5) Connect the USB cable to the device
- (6) Download files from the CD
- (7) Reboot the host
- (8) Connect the USB cable to the host and power on the device
- (9) Install the TWAIN driver
- (10) Install the ISIS driver if required

If you have any questions, please contact the distributor and service provider, Imaging 411 via phone at 866-411-4624 or e-mail at [support@imaging411.com](mailto:support@imaging411.com)